

Accessories

• Flat Pin

BI930	PFL12BP	Brass	Box20
BI931	PFL12CP	Chrome	Box20
BI932	PFL12SB	Brown	Box20
BI933	PFL12SS	Satin Silver	Box20
BI934	PFL12WH	White	Box20
BI935	PFL12CG	Champagne Gold	Box20
BI936	PFL12BK	Black	Box20

• Ejma Pin

BI940	PEJ12BP	Brass	Box20
BI941	PEJ12CP	Chrome	Box20
BI942	PEJ12SB	Brown	Box20
BI943	PEJ12SS	Satin Silver	Box20
BI944	PEJ12WH	White	Box20
BI945	PEJ12CG	Champagne Gold	Box20
BI946	PEJ12BK	Black	Box20

• Flat Wedge

BI950	WFL13BP	Brass	Box20
BI951	WFL13CP	Chrome	Box20
BI952	WFL13SB	Brown	Box20
BI953	WFL13SS	Satin Silver	Box20
BI954	WFL13WH	White	Box20
BI955	WFL13CG	Champagne Gold	Box20
BI956	WFL13BK	Black	Box20

• Ejma Wedge

BI960	WEJ16BP	Brass	Box20
BI961	WEJ16CP	Chrome	Box20
BI962	WEJ16SB	Brown	Box20
BI963	WEJ16SS	Satin Silver	Box20
BI964	WEJ16WH	White	Box20
BI965	WEJ16CG	Champagne Gold	Box20
BI966	WEJ16BK	Black	Box20

Zeta

• UPVC Window Handle Lock

BI901	ZE5000BP-50C-CL	50mm	Clam	Brass	Box10
BI903	ZE5000WH-50C-CL	50mm	Clam	White	Box10

IMPORTANT PRODUCT INFORMATION

Wedges

There will be two new wedges which will replace all of the current types of fastener wedges. These have more benefits and advantages.

Two Types – Narrow and Wide

The new designs are W19 “narrow” style and W24 “wide”. The base of each wedge is combined bevelled and flat. This in addition to a good lead on angle on the wedging spigot, allows one wedge to suit both flat and bevelled window frames.

Benefits

This new designs means - smoother closing of windows, reduced stockholding as one wedgewill suit all Basta and Shaw fasteners and spigot is longer which means better handgrip when operating.

The new wedge codes are W19 and W24 – all other codes will become obsolete – eg 1370WFL13BP – will become 1370W19BP. These will be phased in during August 2008.

Pins

There will be two new pins - P23 (Flat Pin with 13 mm screwhole backset) and P27 (9° Bevel with 13mm screwhole backset). These will join the existing Basta Pins PEJ 12 and PFL 12. These four Pins will suit flat or bevelled window sections and also 16mm and 20mm stay backset. The pins suit both Shaw and Basta type Casement Stays and come in all the specified finishes.

These will be phased in during August 2008. All other pins and wedges will become obsolete as stocks are exhausted. If you need any information contact our Sales Team on 01473225225.

